MONTAGE ANLEITUNG

„slight“ und „slight long“

Blaser / Sauer 303 / Sauer 404 / Weaver-Picatinny / Merkel / Tikka T3

1

1. Montieren auf Montagebasis
Zum Einstellen der Montage muss diese auf die entsprechend vorgesehene Montagebasis aufgesetzt werden. Wurden die Einstellschrauben entsprechend geöffnet, ist ein problemloses Aufsetzen der Montage bei 90° geöffnetem Klemmhebel auf die Montagebasis jederzeit möglich (Bild 1).

2

2. Schließen des Klemmhebels
Zum exakten Einstellen der Montage muss der Klemmhebel geschlossen werden (Bild 2).

3

3. Einstellen der Klemmkraft
Ein gleichmäßiges Anziehen der beiden Einstellschrauben (Bild 3) ermöglicht nun das Einstellen der Klemmkraft. Je größer das Anzugsmoment gewählt wird, desto größer wird die Klemmkraft und die damit direkt zusammenhängende Schließ- und Öffnungskraft des Klemmhebels (Bild 2). Das Anzugsmoment der Einstellschrauben sollte so groß gewählt werden, dass ein Betätigen des Entriegelungsknopfes (Bild 4) gerade noch möglich ist.

4

4. Überprüfen der Einstellung
Bei demontierter und eingestellter Montage ist sicherzustellen, dass ein noch verfügbarer Verstellbereich gewährleistet ist, in dem man überprüft, ob sich der geschlossene Klemmhebel noch geringfügig in den Montagegrundkörper eindrücken lässt.

INNOGUN
Neumühle 8
97727 Fuchsstadt
Tel.: +49 (0) 9732 / 786 466 0
Fax: +49 (0) 9732 / 786 466 6
info@innogun.de
www.innogun.de

INSTALLATION MANUALL

„slight“ and „slight long“

Blaser / Sauer 303 / Sauer 404 / Weaver-Picatinny / Merkel / Tikka T3

1

1. Install on system
Loosen the adjusting screws first. Open both levers to 90°. Setting the mount is now possible (Fig.1).

2

2. Closing the levers
To adjust the mount both levers must be closed (Fig.2).

3

3. Adjusting the clamp preasure
Tightening the two adjusting screws evenly (Fig.3) now enables the clamping force to be adjusted. The greater the tightening torque, the greater the clamping force and the related closing and opening force at both levers (Fig. 2). The choosen tightening torque should just allow using the release button (Fig.4) by hand.

4

4. Check the setting
Dismantle the mount and close the levers. The setting should guarantee a slight over push of both levers inside the mount body.

INNOGUN
Neumühle 8
97727 Fuchsstadt
Tel.: +49 (0) 9732 / 786 466 0
Fax: +49 (0) 9732 / 786 466 6
info@innogun.de
www.innogun.de